


INSTRUCTION MANUAL

IFH-2



Introduction

To get the most out of your new fan heater, please read through these instructions and the attached safety regulations before use. Please also save the instructions in case you need to remind yourself of the fan heater's functions at a later date.

Technical specifications

Voltage/frequency:	240V ~ 50Hz
Power rating:	2,000 W
Settings:	3 (650 W, 1,300 W and 2,000 W)
Temperature:	Continuously adjustable 0-85 °C
Dim.:	243x303x380mm
Weight:	4.76kg

Requires at least a 10 A fuse
Housing of steel plate and heat-resistant lacquer
Supplied complete with cord and plug

The fan heater dials



1. Function selector with three power settings
2. Thermostat dial

Special safety regulations


- The fan heater is not suitable for use outdoors in damp weather, in bathrooms or in other wet or damp environments.
- Please note that the fan heater can become very hot and should, therefore, be placed at a safe distance from flammable objects such as furniture, curtains and similar.
- Do not cover the fan heater.
- Do not place the fan heater immediately under a wall socket.
- Do not connect the fan heater using an on/off timer or other equipment which can automatically switch the device on.
- The fan heater must not be placed in rooms where flammable liquids or gases are used or stored.
- If an extension cord is used, it must be as short as possible and always be fully extended.
- You must not connect other appliances to the same mains socket as the fan heater.



- Meaning of crossed-out wheeled dustbin:
Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.
Contact your local government for information regarding the collection systems available.
If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.
When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.

Installation Requirement

If the fan heater is to be permanently installed, the following instructions must be observed:



Use

- Position the fan heater so that it stands upright on a firm surface and at a safe distance from wet environments and flammable objects.
- Connect the fan heater to the mains.
- Set the thermostat dial to the maximum temperature.
- The fan heater will switch on when the function selector is set to one of the three power settings.
- Once the room reaches the required temperature, you should turn the thermostat dial slowly counter-clockwise until the fan heater switches off. The fan heater now starts and stops automatically and thus keeps the room temperature constant.