



**FANMASTER**  
COOLING HEATING VENTILATION EXTRACTION



## **FILTER CHANGE**

**For IPFC-075, IPFC-15 & IPFC30**





**FANMASTER**  
COOLING HEATING VENTILATION EXTRACTION






**FANMASTER**  
COOLING HEATING VENTILATION EXTRACTION

4. REMOVAL OF THE FILTER.

5. Remove pipe and  
reinstall pipe into new  
filter





**FANMASTER**  
COOLING HEATING VENTILATION EXTRACTION

Loosen this screw then  
remove the filter.  
For assembly reverse this  
procedure.

