






# ASSEMBLY INSTRUCTIONS



# WHAT'S INCLUDED

| PART  | QTY      | IMAGE  |
|---|----------|--|
| <p><b>Air outlet assembly</b><br/>           8 x top panels<br/>           8 x support brackets<br/>           4 x bottom panels<br/>           32 x louvres<br/>           1 x fan guard</p> | <p>1</p> |    |
| <p><b>Body</b></p>  | <p>1</p> |    |
| <p><b>Castors</b><br/>           (located inside body)</p>  | <p>4</p> |  |
| <p><b>PopRivets/Screws/<br/>           Accessories</b><br/>           (located inside body)</p>   |          |  |
| <p><b>Control Panel +<br/>           Enclosure</b><br/>           (located inside body)</p>   | <p>1</p> |  |
| <p><b>Remote Control</b><br/>           (located inside body)</p>   | <p>1</p> |  |
| <p><b>Instruction Manual</b><br/>           (located inside body)</p>   | <p>1</p> |  |

# TOOLS REQUIRED

- Powered drill with Philips head bit
- Rivet gun (preferably air powered)

# VIDEO INSTRUCTION



**WATCH ME**

# PRODUCT INFORMATION




**SCAN ME**

# ASSEMBLY INSTRUCTIONS

RECOMMEND 2 PERSONS FOR ASSEMBLY

## 1st Stage - Unpack & Locate Accessories Box:

- Remove body from the carton
- Remove side panel (with yellow label) to access inside of body.



- Locate box with castors, instruction manual, control panel, remote & accessories.



## 2nd Stage - Attachment of Castors

- Place down the carton or blanket on the floor
- Carefully lay the body on its side
- Attach 4 x castors with bolts & washers supplied
- Lock all 4 brake functions and lift unit into upright position.

## 3rd Stage - Assembly & Attachment of Air Outlet


- Locate 8 x top panels, 8 x support brackets, 4 x bottom panels, 32 x louvres & 1 x fan guard.



Top Panels

Bottom Panels




Louvres




Fan guard

Support Brackets

- Attach the top panels (8) using the pop rivets supplied.




- Attach the support brackets (8) to the top panel using the pop rivets supplied.









- Install the rubber grommets into the support brackets.
- Attach the louvres (32) into the air vent (8 sections).

Rubber Grommets





Louvres

- Attach the bottom panels (4) to the support brackets with the pop rivets supplied.






- Attach fan guard to air outlet with pop rivets & washers.



- Attach air outlet to body with screws provided.



### 4th Stage - Cabling & Connection:

- Insert control panel into enclosure bracket (locate controller cable which is the front)
- Attach enclosure bracket to body with screws supplied
- Locate cable - controller cable (black)
- Connect controller cable (black) to control panel
- Replace side panel
- Ready to plug and play.

